


Guidelines on Using a Voltmeter to Locate Power and Ground

1. First set your voltmeter to the continuity setting (should beep when you touch the red and black probes together, telling you they are shorted).
2. Find a ground on the car somewhere, like a bolt under the dash, or a metal cross member.
3. Put the black probe on that ground, and touch the back of each exposed wire connector in the mirror harness with the red probe.
4. For each wire that beeps, that means that wire is grounded. Turn the ignition to the on position, then back to off, and make sure it beeps regardless of the ignition position.
5. Put the voltmeter into VDC mode, to measure DC volts, turn the ignition to the on position.
6. Put the black probe on the ground wire found in #4.
7. Touch each of the wires in that harness with the red probe, and note which one(s) gives you +12-14 volts, turn the ignition off to verify that the volt readings go down to zero or close to zero.
8. That should define which two ports in that harness into which you would plug the MirrorTap, the black Prong into #4 above, and the Red to #7.

“Power Up” Your Radar Detector by TAPPING Into Your Rear View Mirror’s Wire Harness



*Innovative Design And
Precision Manufacturing*

For more information please visit
WWW.MIRRORTAP.COM

©2021 J28 Design Inc. 07/21



Radars Detector Power Cord With In Line Fuse Corvette C8

.080" WIDE TAP X 15" OVERALL LENGTH
RJ11 CONNECTOR



MT-5015



PART# MT-5015

RADAR DETECTOR POWER CORD
WITH IN LINE FUSE



INSTALLATION INSTRUCTIONS FOR
THE C8 CORVETTE AUTO DIMMING
REAR VIEW MIRROR

INSTALL VIDEO →




The MirrorTap Power Cord (MTPC) utilizes an in line fuse to help protect your radar detector and your vehicle's electrical system.

1 - Sit in the passenger's seat and position the rear view mirror towards the drivers side of the vehicle as far as it will go. This will allow better access to the mirror's wire harness. Use a trim tool to remove the plastic housing from the mirror which will expose the molex plug.



2 - Insert the two Taps of the MirrorTap Power Cord (MTPC). The BLACK Tap wedges against the bottom of the BLACK ground wire and the RED Tap wedges against the bottom of the RED +12 volt switched wire as shown below. **DO NOT** use excessive force trying to insert the Taps.



3 - After both Taps are installed, plug in your device to verify it powers on and off with the ignition. Reinstall the plastic cover back onto the mirror. If you are installing a BlendMount, be sure to position the Power Cord into the open channel on the right side (passenger side) of the BlendMount Top Plate.



J28 DESIGN INC. will not be held responsible for any damage to, interference with, or malfunction of your vehicle's electrical system resulting from installation or use of the MTPC. Consult with your vehicle's dealer for any questions about your vehicle's electrical system. If you do not agree to these terms, do not use this product and return it for a full refund.

